

KOPIMASK

Technical Information

TDS

ADIGUM

Gum to prepare and preserve Offset Plates

DESCRIPTION

Processing and preserving gum, particularly suitable for use in automatic equipment, both for CtP and conventional plates.

APLICATIONS

Very suitable for automatic processing equipment.

Although it is possible the manual gumming, we do not recommend because of low viscosity of ADIGUM.

PROPERTIES

With little tack to prevent sticking Quick drying Easy to recover

SPECIFICATIONS

Color	Brown
pH	4,5
State	Liquid
Concentration	Max. dilution 1:2 (in processing equipment)

STORAGE

Do not expose to temperatures below 5°C or up to 35°C. Expiration 24 moths for closed package and under correct temperature conditions.

PACKAGING

Drum 10 L / Drum 20 L

HOW TO USE

- Dilute ADIGUM according to characteristics of processing equipment and plates. Habitually between 1:1 and 1:2 in water.
- 2 For manual gumming we recommend not dilute ADIGUM.

