



## KOPI GLASMAT PASTE N°2

### Glass engraving-matting paste

#### DESCRIPTION

Engraving–matting special paste suitable for Screen Printing application in every type of glass ( except for borosilicate i.e. PYREX) . By using it, a fast engraving design or matt looking image can be obtained in a few minutes, which keep permanently. Is also works effectively on glazed ceramic surfaces

#### APLICATIONS

- Matting glass
- Engraving letters, logos, etc...on glass surfaces
- Decoration of mirrors
- Glazed ceramic effects

#### PROPERTIES

- Easy to apply
- Permanent matting effects

#### SPECIFICATIONS

Color	Pink
Physical form	Paste
Corrosive	Yes

#### STORAGE

Do not expose to temperatures below 5°C or up to 35°C. Expiration 24 months for closed package and under correct temperature conditions.

#### PACKAGING

Box 12 L (12 x 1L) / Box 20 L (4 x 5 L)

#### HOW TO USE

- 1 Prepare the KOPI-GLASMAT PASTE N°2 for printing, according to the desired texture pure or adding up 1 part of KOPI-GLASMAT Thinner per 5 parts of KOPI-GLASMAT Paste.  
  
Stir it using only plastic or wooden utensil, because the product rusts most of metals
- 2 Bear in mind that this product must be at a temperature between 22°C to 26°C.  
  
In case of having been exposed to low temperatures, the product may be much solidified and crystals have even formed. Warm the product between 25 and 30 ° C (in a bath), crystals disappear and recover its texture.





## KOPI GLASMAT PASTE N°2

### Glass engraving-matting paste

- 3 We advise to work with screens of 34 to 49 threads per cm and with water-resistant emulsions, like our emulsions ROTOMASK CS and ZOICO COAT WR.
  
- 4 The glass must be clean and degreased, dried and at room temperature, before the engraving.  
  
If the glass is cold, you will not obtained a good engraved.
  
- 5 Use the paste like ink, and to get a good cover on the glass, cover uniformly the print area.  
  
Wait for 3 to 5 minutes for KOPI-GLASMAT reaction on the glass.  
Clean KOPI GLASMAT from glass with pressurized water.  
Good ventilation in the working place is advisable.
  
- 6 Screens should be cleaned with water immediately after use, because KOPI-GLASMAT may close the mesh if it dried.  
All strips and devices should be carefully washed once the printing is completed.

