

KOPIMASK

Technical Information

TDS

PREPAGUM

Gum to prepare and preserve Offset Plates

DESCRIPTION

Processing and preserving gum, particularly suitable for long term store.

APLICATIONS

Very suitable for manual use.

Although it is possible for automatic processing equipment, we recommend a dilution 1:1 - 1:2.

PROPERTIES

With little tack to prevent sticking Quick drying Easy to recover

SPECIFICATIONS

Color	Green
pH	4,0
State	Liquid
Concentration	Max. dilution 1:2 (in processing equipment)

STORAGE

Do not expose to temperatures below 5°C or up to 35°C. Expiration 24 moths for closed package and under correct temperature conditions.

PACKAGING

Box 20 L (4x5 L) / Drum 20 L

HOW TO USE

- 1 Dilute PREPAGUM according to characteristics of processing equipment and plates. Habitually between 1:1 and 1:2 in water.
- 2 For manual gumming we recommend not dilute PREPAGUM.



D09.04/1 F8C2 06/05/2015

The data here contained is the more accurate as possible, based on our present knowledge. Nevertheless, no guarantee regarding its reliability can be given as we cannot anticipate every possible application. For the same reason our products are sold without guarantee and under the condition that users will make their own tests in order to value if the product satisfies their necessities. KOPIMASK, S.A. reserves its rights to make any modifications without previous warning.